

Serie MPZ



• Zum Anbau von Potentiometer To mount external potentiometer	1...3 (2W)
• Anzahl Potentiometer Number of potentiometer	100R...50K (Ω)
• Widerstandswerte Resistance	100R...50K (Ω)
• Endlagenkontakte einstellbar Adjustable limit switches	2
• Nutzkontakte (frei programmierbar) Program channels (free setting)	1...4
• Schnellbefestigung Quick rail mounting	35 DIN 46277 / EN 50022



Application:

- Motorized potentiometers are basically the best in the field of control and regulation techniques
- The possibility to mount several potentiometers on the same shaft allows also a remote display of the position of the potentiometer
- Supplementary cams can be used to give limit signals depending on the position of the potentiometer
- Supplementary cams can also be used to offset a residual resistance of the potentiometer at the zero point
- One supplementary cam can be used as zero point interlocking

Design:

- High precision wire-wound potentiometer with high resolution and linearity
- Potentiometer directly driven by the cam shaft
- Two adjustable limit switches controlling the rotation angle of the potentiometer
- Solid mechanical Stopps preventing damage to potentiometers
- Available with AC or DC motors
- Friction clutch protecting the unit when manually operated
- The modular design allows quick delivery practically without delay, voltage resistance and cycle time according to your requirements

Outline drawing



Serie MPZ

Order key

MPZ41 04 1 C1 1 1 0

incl. 1 Potentiometer, each further costs additionally in accordance with price list accessories
max. 3 Potentiometer

Size / Dimension (mm) / Number of switches:

4	=	2 Switches	2 Adjustable limit switches (NK4101/20%) + 0 Program channels free setting (NK4201)
6	=	4 Switches	2 Adjustable limit switches (NK4101/20%) + 2 Program channels free setting (NK4201) 1 Program key (PSN)
9	=	6 Switches	2 Adjustable limit switches (NK4101/20%) + 4 Program channels free setting (NK4201) 1 Program key (PSN)

Cycle times (sec.):

1	=	20s	2	=	30s	3	=	45s
4	=	60s	5	=	90s	6	=	120s

Synchronous motor: Power supply (AC / DC) Frequency 50Hz (60Hz)

	CW	CCW	
C1	= 24	/ 24V	AC
C2	= 48	/ 48... 50V	AC
C3	= 110	/ 110... 120V	AC
C4	= 220	/ 220... 240V	AC
G1	= 24	/ 24V ± 0.1	DC
G2	= 12	/ 12V ± 0.1	DC
			On request

10-Turn-Precision wire wound potentiometer (Type DPZ_2W): Resistance

1	=	100 Ω	2	=	200 Ω	3	=	500 Ω	4	=	1K Ω
5	=	2K Ω	6	=	5K Ω	7	=	10K Ω			

10-Turn-Precision wire wound potentiometer (Type DPZ_2W): Resistance

8	=	2.5K Ω	9	=	20K Ω	10	=	50K Ω
---	---	---------------	---	---	--------------	----	---	--------------

Wire-wound potentiometer: Resistance

0	=	-
1	=	PRSG.2
2	=	PSG.2
3	=	PRSG.3
4	=	PSG.3


Ex.: MPZ4104-7-G2-1094

meant for the potentiometer choice:

R1=50K Ω , R2=20K Ω , R3=1K Ω

Special products will be produced under a new article number.

Serie MPRZ



• Feindrahtpotentiometer Wire-wound potentiometer	R1...R3 (2W)
• Widerstandswerte Resistance	100R...50K (Ω)
• Endlagenkontakte einstellbar Adjustable limit switches	2
• Nutzkontakte (frei programierbar) Program channels (free setting)	1...4
• Rückwand- Schnellbefestigung Quick rail base mounting	35 DIN 46277 / EN 50022


Application:

- Motorized potentiometers are basically the best in the field of control and regulation technics
- The possibility to mount several potentiometers on the same shaft allows also a remote display of the position of the potentiometer
- Supplementary cams can be used to give limit signals depending on the position of the potentiometer
- Supplementary cams can also be used to offset a residual resistance of the potentiometer at the zero point
- One supplementary cam can be used as zero point interlocking

Design:

- High precision wire-wound potentiometer with high resolution and linearity
- Potentiometer directly driven by the cam shaft
- Two adjustable limit switches controlling the rotation angle of the potentiometer
- Solid mechanical Stopps preventing damage to potentiometers
- Available with AC or DC motors
- Friction clutch protecting the unit when manually operated
- The modular design allows quick delivery practically without delay, voltage resistance and cycle time according to your requirements

Outline drawing



Serie MPRZ

Order key

MPRZ41 04 1 C1 1 1 0

incl. 1 Potentiometer, each further costs additionally in accordance with price list accessories
max. 3 Potentiometer

Size / Dimension (mm) / Number of switches:

4 -->Size

55 mm -->Dimension (L)

04 = 2 Switches

2 Adjustable limit switches (NK4101/20%) + 0 Program channels free setting (NK4201)

5 -->Size

63 mm -->Dimension (L)

05 = 3 Switches

2 Adjustable limit switches (NK4101/20%) + 1 Program channels free setting (NK4201)

1 Program key (PSN)

6 -->Size

71 mm -->Dimension (L)

06 = 4 Switches

2 Adjustable limit switches (NK4101/20%) + 2 Program channels free setting (NK4201)

1 Program key (PSN)

Cycle times (sec.):

1	= 30s	2	= 45s	3	= 60s
4	= 90s	5	= 120s	6	= 180s

Synchronous motor: Power supply (AC / DC) Frequency 50Hz (60Hz)

	CW	CCW	
C1 = 24	/	24V	AC
C2 = 48	/	48... 50V	AC
C3 = 110	/	110... 120V	AC
C4 = 220	/	220... 240V	AC
G1 = 24	/	24V	± 0.1 DC
G2 = 12	/	12V	± 0.1 DC
			On request

Wire-wound potentiometer: Resistance

1	= 100Ω	2	= 200Ω	3	= 500Ω	4	= 1KΩ	5	= 2KΩ
6	= 5KΩ	7	= 10KΩ						

Wire-wound potentiometer: Resistance

8	= 2.5KΩ	9	= 20KΩ	10	= 100KΩ
---	---------	---	--------	----	---------

Wire-wound potentiometer: Resistance

0 = -

1 = PRSG.2

2 = PSG.2

3 = PRSG.3

4 = PSG.3

Ex.: MPRZ4106-5-G1-**721-0**

meant for the potentiometer choice:

R1=10KΩ, R2=200Ω, R3=100Ω

Special products will be produced under a new article number.

Serie MPZD



- 1-3 Feindrahtpotentiometer 2W/100 Ohm – 20 KOhm / Precision 10 turns potentiometer
- 2 Hochlaufzeiten / 2 Cycle time:
 - T1 = schneller Rücklauf / fast zero set
 - T2 = Programmablauf Max./Min. / Program duration Max./Min.
- 2 programmierbare Endlagekontakte / 2 Adjustable limit switches
- 1-7 programmierbare Nutzkontakte / 1-7 Adjustable program channel



Application:

- Motorized potentiometers are basically the best in the field of control and regulation techniques
- The possibility to mount several potentiometers on the same shaft allows also a remote display of the position of the potentiometer
- Supplementary cams can be used to give limit signals depending on the position of the potentiometer
- Supplementary cams can also be used to offset a residual resistance of the potentiometer at the zero point
- One supplementary cam can be used as zero point interlocking

Design:

- High precision wire-wound potentiometer with high resolution and linearity
- Potentiometer directly driven by the cam shaft
- Two adjustable limit switches controlling the rotation angle of the potentiometer
- Solid mechanical Stopps preventing damage to potentiometers
- Available with AC or DC motors
- Friction clutch protecting the unit when manually operated
- The modular design allows quick delivery practically without delay, voltage resistance and cycle time according to your requirements

Outline drawing



Serie MPZD

Order key

MPZD41 04 1 1 C1 C1 1 1

Dimension / Size (mm) / Number of switches:

4 -->Dimension

55 mm -->Size (L)

04 = 2 Switches

2 Adjustable limit switches (NK4101/20%) + 0 Program channels free setting (NK4201)

5 -->Dimension

63 mm -->Size (L)

05 = 3 Switches

2 Adjustable limit switches (NK4101/20%) + 1 Program channels free setting (NK4201)

1 Program key (PSN)

6 -->Dimension

71 mm -->Size (L)

06 = 4 Switches

2 Adjustable limit switches (NK4101/20%) + 2 Program channels free setting (NK4201)

1 Program key (PSN)

9 -->Dimension

95 mm -->Size (L)

09 = 7 Switches

2 Adjustable limit switches (NK4101/20%) + 5 Program channels free setting (NK4201)

1 Program key (PSN)

Cycle times (T1):

1 = 30s 2 = 60s 3 = 100s 4 = 150s 5 = 180s 6 = 300s

7 = 10min. 8 = 15min. 9 = 20min. 10 = 30min. 11 = 60min.

Cycle times (T2):

1 = 30s 2 = 60s 3 = 100s 4 = 150s 5 = 180s 6 = 300s

7 = 10min. 8 = 15min. 9 = 20min. 10 = 30min. 11 = 60min.

Synchronous motor 1: Power supply (AC / DC) Frequency 50Hz (60Hz)

	CW	CCW	
C1 = 24	/	24V	AC
C2 = 48	/	48... 50V	AC
C3 = 110	/	110... 120V	AC
C4 = 220	/	220... 240V	AC
G1 = 24	/	24V ± 0.1	DC
G2 = 12	/	12V ± 0.1	DC
			On request

Synchronous motor 2: Power supply (AC / DC) Frequency 50Hz (60Hz)

	CW	CCW	
C1 = 24	/	24V	AC
C2 = 48	/	48... 50V	AC
C3 = 110	/	110... 120V	AC
C4 = 220	/	220... 240V	AC
G1 = 24	/	24V ± 0.1	DC
G2 = 12	/	12V ± 0.1	DC
			On request

10-Turn-Precision wire wound potentiometer (Type DPZ, 2W): Resistance

1 = 100Ω 2 = 200Ω 3 = 500Ω 4 = 1KΩ

5 = 2KΩ 6 = 5KΩ 7 = 10KΩ

10-Turn-Precision wire wound potentiometer (Type DPZ, 2W): Resistance

8 = 20KΩ 9 = 50KΩ

Ex.: MPZD4105-1-C4-C4-718 means for the potentiometer choice:

R1=10KΩ, R2=100Ω, R3=2.5KΩ

Special products will be produced under a new article number.